

MAC driver has been supported for TSC printers

TSC is pleased to announce we have supported the MAC driver. Now TSC printers are compatible with Mac OS v10.6 or later version.

The TSC MAC driver can be found on TSC website. (Home > Service & Support > Downloads)


- ▶ **Manuals**
- ▼ **Driver & software**
 - ▶ Linux driver
 - ▶ Windows driver
 - ▼ **MAC driver**

[TSC MAC driver](#)


Please refer to following information to install the TSC MAC driver, to setup the settings in the driver and to define a label size in the driver.

TSC MAC driver installation guide


1. Double click the tscprinters.pkg to install the MAC driver.




2. Click the Continue button.




3. Click the Install button.




4. Input the Username and Password, and click the Install Software button.




5. Done.




6. Click the Printers and Scanners icon.




7. Click the Add (+) to set up a printer.




8. Click the Add Printer or Scanner...




9. Connect printer to MAC computer thru USB. Select the printer model name. Select the "Other..." under the "Use" drop down menu.




10. Scroll the Other folder to find and select the printer.



11. Click the Add button to install the MAC driver.




12. Done.




How to setup the settings in the driver (TextEdit)


1. Double Click the TextEdit application.




2. Select File\Print.




3. The TextEdit screen.




4. Change the TextEdit to the Printer Features under the drop down menu.




5. The Page Options settings.




6. Change the Page Options to the Media Setting under the “Feature Sets” drop down menu.



7. The Media Setting settings.




8. The Post Print settings.




How to define a label size in the driver (TextEdit)


1. Select File\Page Setup



2. The Page Setup screen.



3. Select the Manage Custom Sizes... under the Paper Size drop down menu.



- Click the Add (+) to define a label size.

The screenshot shows a dialog box for defining a label size. On the left, there is a list of labels with 'Untitled' at the top. Below the list are three buttons: a '+' button (highlighted with a red box), a '-' button, and a 'Duplicate' button. To the right of the list, the 'Paper Size' is set to 215.9 mm Width and 279.4 mm Height. Below that, the 'Non-Printable Area' is set to 'User Defined'. The margins are: Left 6.35 mm, Top 6.35 mm, Bottom 14.11 mm, and Right 6.35 mm. At the bottom right are 'Cancel' and 'OK' buttons. A help icon (?) is at the bottom left.

- Press <tab> key, and input a name for the desired label size.

The screenshot shows the same dialog box as before, but now the '100x50' label in the list is highlighted with a red box. The other elements, including the paper size, non-printable area, margins, and buttons, remain the same.


6. Press <tab> key, and input the Width of the paper size, repeat the above to fill out all of the desired settings, and click the <OK> button to close it.

The screenshot shows a 'Paper Size' dialog box. On the left is a list of paper sizes with '100x50' selected. To the right, 'Paper Size:' is followed by two input fields: '100 mm' (labeled 'Width') and '50 mm' (labeled 'Height'). Below this is the 'Non-Printable Area:' section with a dropdown menu set to 'User Defined'. Underneath are four input fields for margins: '0 mm' for 'Left', '0 mm' for 'Top', '0 mm' for 'Right', and a field containing '0' for 'Bottom'. At the bottom left are '+', '-', and 'Duplicate' buttons. At the bottom right are 'Cancel' and 'OK' buttons. A help icon (?) is at the bottom left.

7. Now the Paper Size will become the just defined one, and press the <OK> button to close it.

The screenshot shows a 'Page Attributes' dialog box. At the top, 'Settings:' is followed by a dropdown menu set to 'Page Attributes'. Below that, 'Format For:' is followed by a dropdown menu set to 'Any Printer'. The 'Paper Size:' dropdown menu is highlighted with a red rectangle and shows '100x50'. Below it, the text '100 by 50 mm' is displayed. The 'Orientation:' section has two icons: a portrait icon (selected) and a landscape icon. The 'Scale:' section has an input field containing '100' followed by a '%' symbol. At the bottom right are 'Cancel' and 'OK' buttons. A help icon (?) is at the bottom left.

8. Select File\Print



9. Select the desired label size under the Paper Size drop down menu.

